C6

SIDE TRANSFER STRAIGHT TRANSFER BOARD 1 CARER

- Position chair as shown.

 Remove centre armrests and footplates.
- Person to lean to side.

 Carer to position transfer board underneath person's buttock.

- Person to place hand flat on far end of transfer board.

 Shuffle across in small movements.
- Once seated on bed, person to lean to one side. Carer to remove board.
 - N.B. Ensure brakes are applied.
 - Care must be taken not to trap fingers under transfer board.
 - Two surfaces should be approximately the same height.





