



FITTING INSTRUCTIONS - CLOSED LEG SUPPORT TYPE SLING (6 Straps) SEATED POSITION



FITTING SLING FROM SEATED POSITION

1

Person to lean forward, slide the sling down the back of the person with the aperture tucked slightly under bottom. Top of the sling should be across the shoulders.




2

Person to lean to one side.
Carer to move leg section of sling underneath thigh.
Repeat for other leg.



3

Bring leg strap X through to the front and under legs. Ensuring the sling remains under the buttocks.



N.B. • It may be easier to place the person's foot on the carer's thigh in order to do this.


FITTING INSTRUCTIONS – CLOSED LEG SUPPORT TYPE SLING (6 Straps)

SEATED POSITION

4 Cross leg straps X, underneath person's legs.

5 Take **left** leg strap (L) and pass it through the **right X** strap.


6 Take **right** leg strap (L) and pass it through **left X** strap.



ATTACHING SLING TO HOIST

7 Connect both leg straps (L) onto spreader bar hooks.

(Refer to Moving and Handling Care Plan (MHCP) for recommended loops)




8 Connect both shoulder straps (S) onto spreader bar hooks.

(Refer to MHCP for recommended loops)

9 Ensure all sling straps are secure.
Operate the hoist.

As the sling starts to lift,
stop and check the sling is comfortable before fully lifting.



- N.B.**
- Ensure that labels and handle(s) are on the outside of the sling.
 - **Never connect X straps to lifting bar.**