


FITTING INSTRUCTIONS

HAMMOCK/ BLANKET TYPE SLING


LYING POSITION




FITTING SLING FROM A LYING POSITION

1

Person to roll onto their side.
Place sling on bed with one half of the sling rolled under itself. Ensure top of sling is lined up with the shoulder.

**2**

Person to roll onto opposite side.
Carer to un-tuck sling.
Person to roll onto their back.



FITTING INSTRUCTIONS

HAMMOCK/BLANKET TYPE SLING

LYING POSITION

ATTACHING SLING TO HOIST

3

Connect both Shoulder straps (S) onto spreader bar hooks.

(Refer to Moving and Handling Care Plan (MHCP)
for recommended loops)

4

Connect both leg straps (L) onto spreader bar hooks.

(Refer to MHCP for recommended loops)

5

Ensure all sling straps are secure.


Operate the hoist.

As the sling starts to lift,

stop and check the

sling is comfortable

before fully lifting.



- N.B.**
- Ensure that labels and handle(s) are on the outside of the sling.
 - If bed side rails are in situ, lower prior to rolling person on bed.