



REMOVING SLING INSTRUCTIONS LYING POSITION




REMOVING SLING FROM A LYING POSITION

1

Once person has been lowered onto the bed.

Untuck the L straps from the X straps. Remove pommel/ X Straps from between legs.



2

Carer to roll the sling.

Sling to be tucked underneath the person.




3

Person to roll on their side, towards to rolled sling.

Carer to untuck sling, starting from leg section.

If sling can not be easily slid away from person, repeat process from point 2.



4

Once sling has been removed, person to lie on back.

