
## C2 CORNER TRANSFER

- Position chairs as shown.

  Remove centre armrests and footplates.
- Lean forward, shuffle bottom to front of seat. Place leading foot forward, and leading hand on far edge of seat.



Shuffle bottom back onto chair.

Replace armrests and footplates.



- **N.B.** Ensure brakes are applied.
  - Two surfaces should be approximately the same height.



