


1

Position chairs as shown.

Remove armrests and footplates, as appropriate.

Lean to side and position transfer board underneath buttock.



2

Place hand flat on far end of transfer board.

Shuffle across board in small movements.



3

Lean to side and remove transfer board.



- N.B.**
- Ensure brakes are applied.
  - Care must be taken not to trap fingers under transfer board.
  - Two surfaces should be approximately the same height.